

DCORE X6464

Digital Audio Server

User Manual

Preface

The purpose of this section is to ensure that the user is able to use the product correctly through this manual in order to avoid danger in operation or property damage. Before using this product, please read the product manual carefully and keep it for future reference.




Outlined

This manual applies to Digital Audio Processors.

This manual describes the functions and use of the various functional modules of the Digital Audio Processor, and guides you through the installation and commissioning of the Digital Audio Processor.

Symbol Conventions

The symbols that may be found in this document are defined as follows.

Symbol	Description
 Note	Provides additional information to emphasize or supplement important points of the main text.
 Caution	Indicates a potentially hazardous situation, which if not avoided, could result in equipment damage, data loss, performance degradation, or unexpected results.
 Danger	Indicates a hazard with a high level of risk, which if not avoided, will result in death or serious injury.

Safety Instructions

Danger

To ensure reliable use of the equipment and the safety of personnel, please observe the following during installation, use and maintenance:

- During the installation and use of the equipment, all electrical safety regulations of the country and the region of use must be strictly observed.
- When installing the equipment, make sure that the input power of the equipment power adapter is 100V-240V, 50/60Hz AC power.
- Keep the working environment well ventilated so that the heat generated by the equipment during operation can be discharged in time to avoid damage to the equipment due to excessive temperature.

- Always unplug the unit's power adapter from the AC power outlet before: A. Removing or reinstalling any part of the equipment; B. Disconnecting or reconnecting any electrical plug or connection of the equipment. Do not operate with electricity.
- There are AC high-voltage parts in the equipment, non-professionals should not disassemble them without permission to avoid the risk of electric shock. Do not repair the equipment privately to avoid aggravating the damage.
- Do not spill any corrosive chemicals or liquids on or near the equipment.
- If the unit emits smoke, odour or noises, turn off the power immediately and unplug the power cord, and contact your dealer or service centre.
- If the appliance is not working properly, contact the shop where you purchased the appliance or the nearest service centre and do not disassemble or modify the appliance in any way. (We cannot be held responsible for problems caused by unapproved modifications or repairs).

**Caution**

- Do not drop objects on the equipment or vibrate the equipment vigorously, and keep the equipment away from locations with magnetic field interference. Avoid installing the equipment in a place where the surface vibrates or is susceptible to shock (neglecting this may damage the equipment).
- Do not use the equipment in high temperature, low temperature or high humidity environments. Refer to the equipment's data sheet for specific temperature and humidity requirements.
- Use the unit indoors, not in an exposed installation where it may be exposed to rain or extreme humidity.
- When the equipment is not used for a long period of time or in a humid and dewy environment, the main power supply of the equipment should be switched off.
- When cleaning the equipment, please use a sufficiently soft dry cloth or other alternatives to wipe the internal and external surfaces, do not use alkaline detergent to wash, and avoid hard objects to scratch the equipment.
- Please keep all the original packaging materials of the equipment properly, so that in case of problems, use the packaging materials to pack the equipment and send it to the agent or return it to the manufacturer for processing. We will not be responsible for any accidental damage in transit not caused by the original packaging materials.

**Note**

- Requirements for the quality of installation and commissioning personnel
Qualifications or experience in the installation and commissioning of audio and video systems and qualifications to perform related work, in addition to the knowledge and operational skills listed below.
 - Basic knowledge and installation skills of audio and video systems and components.

- Basic knowledge and skills in low voltage cabling and wiring of low voltage electronics.
- Basic audio and networking knowledge and skills and the ability to read and understand the contents of this manual.

TABLE OF CONTENTS

Chapter 1 Product Introduction	1
1.1 Introduction	1
1.2 Product Features	1
Chapter 2 Specification	2
Chapter 3 Interface Description	4
3.1 Front Panel	4
3.2 Rear Panel	4
Chapter 4 Instructions for Use	5
4.1 Software Download	5
4.2 PC Software Login Connection	6
4.2.1 Login	6
4.2.2 IP Address Modification	6
4.3 Main Interface	7
4.3.1 Button Function Area	7
4.3.2 File	8
4.3.3 Setting - Device Setting	8
4.3.4 Viewing	16
4.3.5 Language	16
4.3.6 Help	16
4.4 Pre-processing	17
4.4.1 Input Setting	17
4.4.2 Expander	17
4.4.3 Parametric Equalizer	18
4.4.4 Compressor	19
4.4.5 Auto Gain	20
4.4.6 Automixer	21
4.5 Matrix Mixer	23
4.6 Post-processing	24
4.6.1 Delay	24
4.6.2 XOVER	25
4.6.3 Graphic Equalizer	26

4.6.4 Limiter	27
4.6.5 Output Setting	28
4.7 Other Functions	29
4.7.1 Channel Control	29
4.8 Dante Network Audio Routing	30
Chapter 5 Packing List	31

Chapter 1 Product Introduction

1.1 Introduction

This equipment supports a maximum of Dante channel 64 in 64 out, high-quality 21-stage preamplification circuit, DSP processing bus structure, restore high-quality sound, mainly used in a variety of large-scale venues, can meet the theater, concert halls, remote video conferencing, sports stadiums, churches, conference centers, theme parks, public sound reinforcement systems, and other aspects of the application of the needs. Simple operation and powerful performance.

1.2 Product Features

- Comprehensive matrix mixing function, 48kHz sampling rate, 24-bit high performance A/D, D/A converter and 32-bit floating point DSP processor;
- The first 16 inputs DSP audio processing, built-in automatic mixing console, including mixing and automatic mixing functions, but also has a mixing component control function; at the same time with AFC, AEC, ANS module;
- The first 16 inputs per channel: Signal Generator, Expander, 5-band Parametric Equalizer, Compressor, Automatic Gain Control (AGC), Automatic Mixer (AM) etc.;
- The first 16 outputs per channel: Delay, Crossover, Limiter, 31-band Graphic Equalizer , Invert;
- Display shows the IP address;
- Test signal generator, Sine wave, Pink Noise, White Noise, frequency and level magnitude selectable;
- Input phase button, mute button, phantom power button;
- Output mute button, phase button per channel;
- Supports Simplified Chinese, English and Traditional Chinese languages;
- One-click display of all function modules;
- Storing user manual and software with the device;
- Central control code generated in the control software; power failure automatic protection memory function; one-click reset function;
- Channel copy, paste, group control function;
- Supports setting the maximum and minimum volume range for each channel;
- The same host allows 10 users to manage;

- Device name can be modified;
- Editable preset mode, new, delete, modify, one-click reset, preset mode can be stored to computer and one-click reset;
- With camera tracking function, can independently adjust the preset position of a camera, compatible with VISCA, PELCO-D, PELCO-P three control protocols, support for custom commands;
- Ethernet multi-purpose data transmission and control port, can support real-time management of single and multiple devices;
- Intuitive image, simple and easy to understand the graphical software control interface, for customers to bring fast, real-time operating experience;
- The device does not need a CD, comes with installation software, a device for a software version, to solve the troubles caused by the loss of the installation CD and the confusion of multiple software versions;
- Configuration of bi-directional RS232 interface, RS485 interface, standard Ethernet control interface, 8-channel programmable GPIO control interface (customisable inputs and outputs), level support for external inputs 3.3~24V;
- Support 100 groups of scene presets, scene new, save, delete and other functions;
- Intuitive, graphical software control interface, works on Windows XP, 7, 8, 10, 11, etc..

Chapter 2 Specification

Category	Parameter Item	Parameter Description
Peripherals	Input Channels	64 Dante
	Output Channels	64 Dante
	Display	Displays the device IP address
	Control Interfaces	1 RJ45 interface, 1 RS232 interface, 1 RS485 interface, 8 GPIO control interface
Audio processing	Processor	TI 456MHz FLOPS dual-core 32-bit DSP processor; 24-bit A/D and D/A converter, 48kHz sampling rate

	Input Channel	Functional module: Preamplifier 51dB, Signal Generator, Expander, 5-band Parametric Equalizer, Compressor, Automatic Gain Control (AGC), Automatic Mixer (AM) etc..
	Output Channel	Delay, Crossover, 31-band Graphic Equalizer, Limiter
	Frequency Response	20Hz~20KHz, $\pm 0.2\text{dB}$
	Crossover	Three types of high and low pass filters: Butterworth, Bessel and Linkwitz-Riley
	Equalizer	- Parametric Equalizer: Frequency: 20 to 20kHz, Gain: -15 to +15dB, Bandwidth: 0.02 to 4 - Graphic Equalizer: Frequency: 20~20kHz, Gain: -15~+15dB
	Dante network delay	< 1ms
General specification	Operating Voltage	AC 100V~240V, 50Hz/60Hz
	Maximum Power	40W
	Operating Temperature and Humidity	0°C~40°C, 10%~90%RH, No condensation
	Chassis	1U
	Product Dimensions (L×W×H)	482.4mm×260.5mm×44mm
	Net Weight	2.5kg
	Package Dimensions (L×W×H)	590mm×430mm×110mm
	Package Weight	3kg


Chapter 3 Interface Description

3.1 Front Panel



- ① PWR: Power indicator, the indicator light is always on to indicate that the device is powered normally;
- ② SYS: System operation indicator, the indicator will flash once per second to indicate that the system is operating normally;
- ③ Display: Displays the IP address.

3.2 Rear Panel



- ① POWER: Power supply interface, connect 110V-220V AC power supply, warp switch control processor power;
- ② ETHERNET: Network control interface, by connecting this network port, the client computer can debug and monitor the device;
- ③ Dante: Dante network audio transmission interface, equipped with primary and secondary dual network interface, can be used for redundant backup of Dante network signals;
- ④ RESET: Reset button, long press to restore factory settings and restart the processor;
- ⑤ RS232+RS485+GPIO interface: Connect to the control terminal or central control device;
- ⑥ Ground screw: Used to ground the chassis, play accidental leakage safety protection, electrostatic balance and other protective measures.

Chapter 4 Instructions for Use

4.1 Software Download

Installation software source files embedded in the digital audio processor device, download the software simply by entering the device's factory default IP address (default IP: 192.168.1.200) information in the URL address bar of the browser, enter will be able to navigate to the download interface, according to the content of the web interface information click on the download of the software can be, in addition to pay attention to the installation of software before the PC side of the PC, please make sure that PC clients have been Net Framework3.5 or above for Windows system.

Note: Make sure the PC client is in the same network segment as the device IP address (default IP: 192.168.1.200 subnet mask: 255.255.255.0) when you download the software, otherwise you will not be able to access it.

Web page controls as well as downloads:



Software download screen:



4.2 PC Software Login Connection

A screenshot of the PC software login interface. On the left is a login form with the following fields: an IP address field containing "192.168.1.200", a user name field containing "admin", a password field containing "*****", a checkbox labeled "Remember password" which is checked, and a "LOGIN" button. On the right is a "Device List" panel with a "Search" button and a list of devices. The first device in the list is "DSP" with a green checkmark icon and the IP address "192.168.1.200".

4.2.1 Login


Click the [Search] button, when the device list is refreshed, the online device [Model Name] will be displayed in the list column, double-click the corresponding device [Model Name] in the list column to bring up the 'left figure' login box, enter the user name/password input box (default user name: admin, password: 123456), click the [OK] button to complete the login connection to the device. OK] button, then you can complete the login to connect the device. After successful connection, the status bar of the software will display the user name and IP address of the connected device.

4.2.2 IP Address Modification

When the IP information of the device is not in the same network segment as the client, an 'exclamation mark' will appear in front of the model name of the device in the list of settings, at






this time, you only need to double-click on the [model name] to bring up the IP information modification [dialogue box] and then you can modify the IP address.

4.3 Main Interface



4.3.1 Button Function Area



- ①  Button: Device Search Button: Click to search for connectable devices and display device IP;
- ②  Button: Device Connection Button: The IP of the device is known, and you can connect directly by entering the IP address, user name and password in the pop-up box;
- ③  Button: Scene List Button: You can select and view the saved scenes through the list;
- ④  Button: Save Scene button: saves (overwrites) the parameter changes to the selected scene;
- ⑤  Button: Interface lock button: locks the current interface, which must be unlocked with the administrator password.

4.3.2 File

File Setting View Language Help

- ① New: Create a new scene, the parameters are factory configured and only available offline.
- ② Open: Open the locally saved scene.
- ③ Save as: Save the current configuration (i.e. scene) as a file locally.
- ④ Exit: Close the software.

4.3.3 Setting - Device Setting


I. User Setting

ID	User	Type
1	admin	Admin
2	1	User
3		
4		
5		
6		
7		
8		
9		
10		

- ① Initial user name of the device: admin, password: 123456, administrator can add, delete, modify all user information, ordinary users can only modify personal information.
- ② Add a user: Select an empty line in the left list, and enter the new user's information in the right user name and password edit box (should be empty), click "Add" button to add a new user.
- ③ Modify user: first select the user you want to modify in the user list, the user name and password edit box will display the information of the currently selected user, enter the new information and click the "Modify" button.


- ④ Delete User: Select the line in the user list to be deleted, click "Delete" button to delete the user.

II. Net Setting




To view and modify the network address information of the device, enter the Network window, type in the IP address, subnet mask and gateway in the corresponding input boxes, and click the [Apply] button to complete the modification.

III. Serial Setting



Serial window can view or modify the RS232/RS485 serial port number baud rate, check bit, data bit, stop bit settings are complete, click on the [Apply] button to modify the current device's serial port information, such as the need to restore to the initial default value, click on the [Reset] button, you can restore the settings of the parameter can not be empty.


IV. Scene Setting




- ① Load Scene: Enable the currently selected scene, usually used for scene replacement;
- ② Save As: Save the selected scene locally;
- ③ Save: Save the currently running parameters to the selected scene;
- ④ Upload: Upload the scene from PC and overwrite the selected scene;
- ⑤ Rename: Modify the name of the selected scene;
- ⑥ New: Create a new scene file, you can customize the new scene, support up to 100 groups of scenes;
- ⑦ Delete: Select any scene in the list and delete it;
- ⑧ Reset: Restore the currently selected scene to the factory default state;
- ⑨ Restore: Restore all scene configurations to the default configuration and clear all new scenes, only retain the factory default 8 groups of scene files, please use with caution.

V. Voice Setting

The Voice Setting is the camera tracking setting. Camera tracking parameter saving: Each scene can save different camera tracking parameters, firstly, click "Apply" after setting in the camera tracking interface; then click "Save" in the "Scene Control" interface. Then click "Save" in the "Scene Control" interface, the camera tracking parameters will be saved to the corresponding scene automatically.




- ① Tracking type: There are camera tracking and custom commands. Camera tracking is used to control camera rotation by channel input signal; custom command sending is used to send corresponding custom commands to the corresponding port by channel input signal.
- ② Default: When there is no input from all microphones, rotate the camera to the position set by the default Mic or send the associated command defined by the default Mic. The one with # sign indicates the virtual number, which can only be used to set the default microphone.
- ③ Threshold: Means the detected input signal must be greater than or equal to the Tracking Threshold, and the system automatically enables the tracking parameter.
- ④ Speech space: Maximum intermittent time for a valid signal. If you use the microphone to speak, set the response time to 3 seconds, the signal is still regarded as continuously valid within 3S pause in the middle of the speech, and the signal is regarded as invalid if it exceeds 3S.
- ⑤ Switch time: The shortest speaking time required for the camera to switch to a valid position. If you use the microphone to speak, the length of speech must be greater than the "switching time", the channel signal is considered valid, and then the camera will automatically turn to the set position. Usually the "switching time" is greater than the "reaction time".
- ⑥ Duration: The interval time between sending camera switching commands or custom commands, such as 0 means special treatment, only triggered once.



The 'Set Mic Tracking' dialog box contains the following controls:

- Mic NO.:** A dropdown menu with '1' selected.
- Priority:** A dropdown menu with '1' selected.
- Camera track:** A section with an 'Active' checkbox (checked) and four dropdown menus: 'Serial' (232), 'Camera addr' (1), 'Protocal' (PELCO_L_D), and 'Preset' (1).
- Custom command:** A section with an 'Active' checkbox (checked), a 'Serial' dropdown menu (232), a 'Send' button, and a large empty text input area.
- Apply:** A button at the bottom right.

- ⑦ The microphone number generally corresponds to the input channel of the device, i.e. it is the channel number to which the microphone is connected. The microphone number with # is a virtual number, which can only be used to set the default microphone.
- ⑧ The smaller the priority number is, the higher the priority level is. When the priority level is the same, it will be processed in accordance with the triggering priority order; for example, if two microphones are speaking at the same time, the camera will automatically rotate to the preset bit corresponding to the microphone with the small priority number (i.e., the high priority level) or send the command corresponding to the microphone with the small priority number (i.e., the high priority level); however, if the two microphones are with the same priority level, the signal that is checked first will prevail.
- ⑨ Enable this Mic setting: you can set all the microphone parameters in full in advance, but when you use it, only some of them will be enabled according to the actual situation.
- ⑩ Preset points, serial port numbers, camera addresses, protocols and camera-related, must correspond to the actual connection of the camera.
- ⑪ Custom Command means that when the microphone of the matrix checks the input signal (usually when someone speaks), it will automatically send the corresponding command to the defined serial port, and secondly, you can also pre-set the command, but do not check "Enable Custom Command", the device will not send it automatically, but you can still click the "Send" button, and the command in the input box will be sent to the specified serial port at any time.
- ⑫ Click on "Save" to save the parameters to the device, so that the microphone for the channel is now associated with the corresponding camera address. Then use the "Enable Microphone Settings" option to determine whether the microphone settings are valid when tracking is enabled.



The 'Camera setting' dialog box contains the following controls:


- Serial:** A dropdown menu with '232' selected.
- Camera addr:** A dropdown menu with '1' selected.
- Protocal:** A dropdown menu with 'PELCO_L_D' selected.
- Speed:** A dropdown menu with '50' selected.
- Navigation:** A central cross-shaped button with four arrows pointing up, down, left, and right.
- Zoom:** Two buttons labeled 'Zoom in' and 'Zoom out'.
- Position:** Two buttons labeled 'Near' and 'Far'.
- Size:** Two buttons labeled 'Big' and 'Small'.
- Preset control:** A section with a 'Preset' dropdown menu (1) and three buttons: 'Call', 'Save', and 'Clear'.

- ⑬ Camera Setting is a camera debugging interface, generally debug the camera position before tracking starts, and finally the parameters of this part will be saved on the camera.
- ⑭ Firstly, serial port setting, there are 2 serial ports (232, 485), which correspond to the back panel port that the PTZ is connected to;
- ⑮ Next is the camera address and protocol type, please refer to the actual address of the camera for the camera address, and the protocol is related to the camera model;
- ⑯ Lastly the preset point number is the user-defined identification for the camera, and then the adjustment of the up, down, left, right, and focal length, aperture, and other parameters will define the camera's position and settings;
- ⑰ Finally, click "Save" to save the parameters to the camera, "Clear" is to delete the information of the current preset point, "Recall" is used to view the camera saved by the current preset point. "Clear" is to delete the information of the current preset point, and "Recall" is used to view the camera position saved by the current preset point.

VI. GPIO




Output Connection 1:



Firstly, connect a 10K/0.25W resistor between a GPIO pin (e.g. port 2) and "V" on the device (as shown in the figure), the pin will output a low level 0 or a high level 1 according to the change of matrix state, and the level can be

used to trigger another GPIO or other devices.

Output Connection 2 :



Driver relays (control type): Relays can be used to control alarm devices, etc., with built-in current-continuing diodes.

Trigger Type:

- ① Rising edge input: The IO port is held high when there is no input;
- ② Falling edge input: the IO port stays low when there is no input.

Control Type:

- ① Inputs: Scene, Mix, Volume, Channel Mute, System Mute, Serial Command Settings;
- ② Outputs: Scene, Level, Channel Mute, System Mute display.



GPIO Input Example 1

Scene Setting

The PC enters the GPIO-1 control window, selects the [Input] direction, the control type [Scene Setting], the trigger type [Rising Edge], the parameter settings are loaded to [Scene 2], and clicks the [Apply] button at the bottom of the window.

When the device hardware GPIO-1 pin level is pulled high from low, the trigger condition is established and the digital audio processor scene preset will automatically switch to scene 2.



GPIO Output Example 2


Channel mute display

The PC enters the GPIO-2 control window, selects [Output] mode, display type [Channel Mute

Display], trigger type [Output Low, No Output High], parameter setting [Inputs] channel selection [Input 2], and clicks the [Apply] button at the bottom of the window.

When the device input IN2 channel is muted, the corresponding GPIO-2 pin output is '1', and when the IN2 channel is unmuted the output is '0'.

VII. Center Control



The Central Command Generator is able to convert frequently used operations into a 16-character command code for easy invocation by external devices.

Control command types: Scene, Input, Output, Mix, Parametric EQ, Graphic EQ, Expander, Compressor, Auto Gain, Delay, Crossover, Limiter.

4.3.4 Viewing

- ① Open All: open all function module interfaces to display them;
- ② Open Input: open all the input function module interfaces and display them;
- ③ Open Output: open all the output function module interfaces and display them.

4.3.5 Language

Language switching supports Simplified Chinese, Traditional Chinese and English.


4.3.6 Help

- ① Help: View the embedded user documentation of the device;

- ② Upgrade: for updating the system software version;
- ③ About: display software version information.

4.4 Pre-processing

4.4.1 Input Setting




- ① Model type: Analog input or test signal;
- ② Sensitivity: Analog signals can be adjusted by adjusting the sensitivity of the input can be selected, from 24 ~ -27dBu, step 3dBu a grade;
- ③ Mute: mute mode is enabled for the currently selected channel;
- ④ Invert: Inverts the input signal by 180° ;
- ⑤ Phantom power supply: used for condenser microphone power supply, please do not turn on the line input or non-condenser microphone to prevent burning;
- ⑥ Test signal: including sine wave, pink noise, white noise, the system will automatically block the Analog input signal when the test signal is enabled.

4.4.2 Expander

The Expander is to increase the dynamic range of the input according to the user's needs: when the input signal is less than the "threshold", the Expander will compress the input signal according

to the set "ratio", the output level = Threshold - (Threshold - Input Level)/Ratio; when the input signal is greater than the "threshold", it will be output at 1:1, the output level = Input Level. When the input signal is greater than the "Threshold", the output is 1:1 and the output level = input level.



- ① Enable/Pass-through: enable or disable the Expander for the current channel;
- ② Ratio: the decibel number of the dynamic change of the input signal of the Expander/the decibel number of the dynamic change of the output signal of the Expander;
- ③ Start-up time: the time required for the input signal less than the Expander's "threshold value" to enter the expansion state and output according to the set expansion ratio;
- ④ Recovery time: the time required for the input signal to return from the extended state to the original non-extended state.
- ⑤ Reset: restores the parameter to the default value.

4.4.3 Parametric Equalizer


Equalizers are mainly used to modify over-emphasised or missing frequency ranges. Whether the frequency range is narrowed or widened, equalizers can help to repair the narrowed frequencies or widen the frequency range to achieve the ideal signal tone.



- ① Reset: all band filter parameters are restored to the default state;
- ② Enable/Pass-through: enable or disable all band filters;
- ③ Band Pass-Through/Enable: whether the band equalizer is valid or not;
- ④ Centre Frequency: the centre frequency that needs to be equalized;
- ⑤ Gain: the gain/attenuation value at the centre point of the frequency;
- ⑥ Bandwidth: i.e. the influence range of the band around the centre frequency, the larger the value, the larger the bandwidth and the larger the influence range.

4.4.4 Compressor

The compressor is used to reduce the dynamic range of the signal above a user-determined threshold, with the signal level below the threshold remaining unchanged.




- ① Valve: The signal level above this valve starts to reduce the gain. This point is at the inflection point in the input/output curve. For Peak Stop, the threshold to be stopped is set just below the peak level;
- ② Ratio: the compression ratio of the input and output;
- ③ Start Time: the speed of gain reduction processing with which this compressor starts. The shorter the start-up time, the greater the instantaneous change of the signal, the short time gain reduction makes the hearing uncomfortable.
- ④ Release time: the release time determines the moment-to-moment gain change of the compressor. A fast release time raises the subjective level, while a slow release time is more useful for keeping the level under control;
- ⑤ Output fader: the fader controls the output gain of the module. If the compressor reduces the signal level significantly, a boost in output gain may be required to maintain the perceived volume.
- ⑥ Enable/Thru: Enables or disables the compressor for the current channel;
- ⑦ Reset: restores the parameter to its default state.

4.4.5 Auto Gain

The purpose of Auto Gain control is to bring a signal of uncertain level up to the target level while maintaining the dynamic range of the volume. Typical use: For example, when the user speaks in front of the microphone, the distance between the mouth and the microphone will be far away and close to each other, which will cause the output volume to go up and down, or even feel that

the speech is intermittent. Auto Gain is to set the threshold value for the input signal below the threshold in accordance with the ratio of 1:1 output, for the level above the threshold is in accordance with the ratio of direct enhancement, set the target level, the sound signal can be stable output.




- ① Valve: when the signal level is below the threshold, the input/output ratio is 1:1. when the signal level is above the threshold, input/output = ratio. Set this threshold level slightly above the noise ratio of your input signal;
- ② Target Level: the desired output signal level; Auto Gain Control is to automatically control the magnitude of the gain by changing the input/output compression ratio. When a weak signal is input the signal is amplified to ensure the strength of the output sound signal; when the strength of the input signal reaches a certain level, the signal is compressed to reduce the amplitude of the sound output.
- ③ Enable/Pass-through: Enable or disable auto gain for the current channel;
- ④ Reset: restores the parameter to the default state.

4.4.6 Automixer

Automixer are primarily used to automatically operate and control how a traditional mixer with a large number of speech inputs outputs the desired results. Consider a typical conference room scene with ten participants, each with a microphone, if ten microphones are switched on at the same time and only one person is speaking as a result, then the output will definitely not be ideal as the other nine microphones pick up room acoustics, reverberation, etc., which will reduce the output of the entire system.

Each channel of the Automixer has an input, gain level meter and an auto gain, channel fader, priority, and channel mute. Channel Controls Each channel has an "Auto" button that is pressed to add the channel to the Automixer. Channel Mute and Fader are both Auto Gain types. To mute a signal and prevent it from going into the Automixer, turn Mute on and off. The channel fader controls the mix level and direct output level of the channel.



- ① Priority control PR: The higher the value the more gain acquisition capability and the higher the priority, able to reduce the ability of channels with a low priority level to acquire transmission gain. This control defines the priority level with a value between 0 (lowest priority) and 10 (highest priority), and the default value is 5 (standard priority). If all channels have equal priority, set the priority of all channels to 5;
- ② Gain: the overall output gain of the Automixer;
- ③ Slope: similar to the expansion ratio of an extender, the larger the slope value, the more the speaking microphone acquires the transmission gain, the more the non-speaking microphone attenuates the transmission gain; the smaller the slope value, the less the speaking microphone acquires the transmission gain, and the less other non-speaking microphone attenuates.
- ④ Response Time: The time for a microphone to acquire all the transmission gain when it is speaking or the time for other non-speaking microphones to attenuate the transmission gain. The longer the setting, the longer it takes for the speaking microphone to acquire the full transmission gain and the longer it takes for the other non-speaking microphones to attenuate the transmission gain. The shorter the setting, the opposite is true.
- ⑤ Local Output: Select the channel for local output;
- ⑥ Enable/Pass-through: enable or disable the auto gainer for the current channel;
- ⑦ Reset: restores the parameter to its default state.

4.5 Matrix Mixer

Matrix Mixer																		
	1-16	17-32	33-48	49-64														
		IN1	IN2	IN3	IN4	IN5	IN6	IN7	IN8	IN9	IN10	IN11	IN12	IN13	IN14	IN15	IN16	
1-16	OUT1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	OUT2	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	OUT3	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
17-32	OUT4	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	OUT5	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	OUT6	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
33-48	OUT7	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	OUT8	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	OUT9	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
49-64	OUT10	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	OUT11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	OUT12	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	OUT13	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	OUT14	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	OUT15	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	OUT16	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	OUT16	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	

Matrix both signal routing and mixing double multiplexing function, the control logic is horizontal for the input channel, vertical for the output channel, the matrix initialization state is (as shown in the figure above: one-to-one) input and output.


Matrix Mixer

	1-16	17-32	33-48	49-64														
		IN1	IN2	IN3	IN4	IN5	IN6	IN7	IN8	IN9	IN10	IN11	IN12	IN13	IN14	IN15	IN16	
1-16	OUT1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	OUT2																	
	OUT3																	
17-32	OUT4																	
	OUT5																	
	OUT6																	
33-48	OUT7																	
	OUT8																	
	OUT9																	
49-64	OUT10	0,0	0,0	0,0	0,0	0,0	0,0	0,0	0,0	0,0	0,0	0,0	0,0	0,0	0,0	0,0	0,0	
	OUT11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	OUT12	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	OUT13	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	OUT14	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	OUT15	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	OUT16	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
	OUT16	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	

The OUT channel of the mixer is equipped with a gain fader, which allows you to individually control the gain of any output channel with a gain range of (12~72dB).

4.6 Post-processing


4.6.1 Delay



The time interval between the input of a signal to this processor and the output of this processor is generally used to produce other effects such as reverberation or echo, and can equally be used to act as a treatment for auxiliary loudspeakers in larger rendition situations.


- ① Delay time: delay time range (0~2000ms);
- ② Delay distance: delay distance range (0~680m);
- ③ Enable/Pass-through: enable or disable the delayer for the current channel;
- ④ Reset: restore the parameter to the default value.

4.6.2 XOVER




- ① Filter Type: Butterworth/Bessel/Linkwitz-Riley
- ② Slope: 6/12/18/24/30/36/42/48
- ③ High-pass frequency: Cut-off frequency of high-pass filtering;
- ④ Low-pass frequency: cut-off frequency point of low-pass filtering;
- ⑤ High frequency pass-through/enable: enable and disable the high pass filter;
- ⑥ Low frequency pass-through/enable: enable and disable the low-pass filter;
- ⑦ Enable/Straight-through: enable or disable the crossover for the current channel;
- ⑧ Reset: Restores the parameters to the default values.

4.6.3 Graphic Equalizer




- ① Narrowband: narrowband equalization filter; Normal: regular equalization filter; Wideband: wideband equalization filter;
- ② Centre frequency: centre frequency indication of the current equalization filter;
- ③ Gain: Gain indication or control of the current equalization filter;
- ④ Straighten: Restore all the band gains to the default state;
- ⑤ Enable/Pass-through: enable or disable the graphic equalizer for the current channel.

4.6.4 Limiter



- ① Enable/Pass-through: enable or disable the limiter for the current channel;
- ② Threshold: the starting level of the limiter, when the signal is higher than this limit value, the limiter processing module will be activated;
- ③ Recovery time: when the input signal is lower than this setting value, the sound channel will not be turned off immediately, but will be delayed based on this setting value. During this time, as long as there is a signal higher than the "Threshold" limit value, the sound channel will continue to be turned on.
- ④ Compression: The difference between the signal processed by the limiter and the input signal.
- ⑤ Reset: Resets the parameter to its default value.

4.6.5 Output Setting




- ① Mute: Control the output channel mute;
- ② Invert: set the output channel signal 180° inverted.


4.7 Other Functions

4.7.1 Channel Control

I. Input Channel Control and Shortcut



II. Output Channel Control and Shortcut



4.8 Dante Network Audio Routing

In a Dante audio network, the Dante Controller software is required to set up the routing of the various signals accessing the processor. It can realize 1-to-1, 1-to-N mapping operation from input to output within Dante network.

Note: 1, Dante can not run in the Wi-Fi wireless connection environment, is dependent on a reliable and secure wired network environment to transmit perfect audio;

2, Dante Controller software corresponds to the platform of Windows 7, Windows 10, Windows 11, macOS, please select the appropriate software version according to your system platform.

[Click to download the official Dante Controller software Dante Controller](https://www.audinate.com/products/software/dante-controller)

(<https://www.audinate.com/products/software/dante-controller>)

31

Warranty Regulations

The warranty period for this product is 1 year.

During the warranty period, non-man-made damage or performance failures can enjoy a Three Guarantees Service (Repair, Replacement, and Refund Service) .

The warranty card is effective only after being stamped by the sales unit. Alterations will invalidate it!

The following conditions (including, but not limited to) are not covered by the Three Guarantees Service :

1. No warranty card or valid invoice missing, or if the date has exceeded the validity period of the three guarantees services.
2. Damage caused by not following the product instructions for use, maintenance, storage, and management.
3. Mismatch between the product model or code on the warranty voucher and the physical goods.
4. Damage from dismantling or repair by unauthorized service providers.
5. Normal discoloration, wear and tear, and consumption during use of the product are not covered.
6. If the product cannot be used due to the user's network issues, please consult customer service staff.



SHENZHEN S TRACK SCIENCE TECHNOLOGY CO., LTD

Web: www.s-track.com.cn

Tel: +86 755 29983191

Mail: service@s-track.cn

Add: 9F, 1B, Shangzhi Technology Park, Guangming District, Shenzhen City, Guangdong Province, China 518107